NDE and Advanced Actuators for Space Applications at JPL

Yoseph Bar-Cohen, yosi@jpl.nasa.gov

http://ndeaa.jpl.nasa.gov/

Seminar presentation, Japan, June 1999

What is NDEAA?

Nondestructive Evaluation and Advanced Actuators

R&D FOCUS AREAS

elastic waves. Mechanisms and devices that are driven by acoustic or

Medical treatment	NDE & diagnostics	High frequency (MHz)
Actuation	Sono-tomography	
Large amplitude	Small amplitude	



JPL's NDE & Advanced Actuators (NDEAA) Group TOPICS OF R&D

NDE

backscattering Materials properties and flaws characterization using leaky Lamb waves (LLW) and polar

Advanced Actuators

- Low Mass Muscle Actuators (LoMMAs) using electroactive polymers
- Ultrasonic motors (USM) and piezopumps

Ultrasonic Medical Diagnostics and Treatment

- High power ultrasound (FMPUL)
- Acoustic Microscopy Endoscope (200MHz)


TeleRobotics

- Multifunction Automated Crawling System (MACS) and autonomous scanner platforms
- Noninvasive geophysical probing system (NGPS) for Mars exploration, gas pipes and coal-mines
- Ultrasonic and coring for planetary exploration

Ultrasonic Leaky Lamb Wave* NDE Method


- Very good agreement between theoretical analysis and experimental data
- An efficient setup was developed for data acquisition
- An inversion algorithm was developed to allow determination of the elastic constants
- Method was applied to NDE of defects imaging and characterization

LLW C-scan of [0]₈
Gr/Ep Laminate



^{*} Phenomenon discovered in composite materials by Y. Bar-Cohen in Aug. 1982


Leaky Lamb Wave (LLW) Test System




ULTRASONIC POLAR BACKSCATTERING*


unique imaging of their configuration discontinuities allows to perform Preferred scattering characteristics of







- eta angle between Y-axis and the transmitter beam trajectory on the layer plane



Imaging of fiber orientation


^{*} Phenomenon discovered by Y. Bar-Cohen in Sept. 1979

Multifunction Automated Crawling System (MACS)

MACS is a miniature crawler that forms an enabling technology for automated NDE and maintenance.

It has the following characteristics:

- Operation in any position including mounting vertically and attached upside down.
- Designed to allow rotation on the spot upon a command from the control system
- Ability to move on complex shape structures.
- Effective carrying capability of about 1:10 weight ratio.
- A large carrying platform.




HIGH POWER ULTRASOUND TREATMENT

JPL/CSMC/QMI Frequency Modulated high Power Ultrasonic (FMPUL) METHOD


Angiographic example of the effect of transcutaneous ultrasound on the left iliofemoral artery of a rabbit.

Blocked artery




nt

Flash photography dark-field view of cavitations formed in water using high power ultrasound.



COAL LAYERS AND MINES STATE-OF-STRESS EXAMINATION USING NON-INVASIVE SURFACE WAVE MEASUREMENTS


Ultrasonic cross section imaging of a bridge slab




60

Ultrasonic response from two typical areas of a


tested bridge



ULTRASONIC ROCK DRILLING









Flexible drilling wire

MINIATURE LOW-POWER ULTRASONIC CORE DRILLER (UTCD)






General view of the corer actuator and end effector



Corer finite element modeling




Lithotripsy unit with actuator and sting



Ultrasonic motors (USM)

Ultrasonic motors are driven by traveling flexure waves induced by a ring-shape sequentially-poled piezoelectric wafer(s).




JPL progress


- USMs are analytical modeled for efficient design and for operation in cryovac conditions.
- Experimental setup developed for investigation of the cryovac performance.
- USM were made with segmented and reversed wafers (patent pending).
- Miniature drive electronics is developed.
- The JPL's USM were shown to operate more than 5 times longer than the leading commercial USMs.
- Technology transfer to two major corporations for mass production applications is currently in advanced phases.



Cryovac response of USMs



An Ultrasonic C-Scan image of a 1.2" diameter stator (Shinsei) that was subjected to 150°C and 16 mTorr for over 67-h.




Torque-speed performance of a JPL/QMI USM subjected to 150°C and 16 mTorr (lasted 336 hours)




FINITE ELEMENT ANALYSIS OF USM

- various design configurations. Finite element model was developed to analyze the behavior of ultrasonic motors in response to
- MIT using an interferrometric system. Predictions of the frequency response of USM's stators were corroborated experimentally at



Detailed Modeling Using ANSYS FEM Analysis




Motor wave travel of $1/4 \lambda$



ELECTROACTIVES POLYMERS (EAP) SAMPLE HANDLING AND MANIPULATION

arm **EAP Robotic**









APPLICATIONS OF BENDING EAP ACTUATOR

Gripper






















Low Mass Muscle Actuators (LoMMAS)




Gripper using bending **EAP fingers**



Longitudinal EAP lifter using



Deflection vs. voltage at RT and -100°C.







IPMC - EAP BENDING ACTUATOR

Deflection (Cm)1.80
0.20
0.80
0.20


+ 0.1 Hz + 0.5 Hz + 1.0 Hz

0.00

2.00

6.00

4.00 Voltage (V)



EAP STATUS

- Electroactive Polymers are emerging as effective displacement actuators
- enabling unique capabilities changing the paradigm about robots construction. These materials offer the closest resemblance of biological muscle potentially
- driven by EAP including dust wiper, gripper and robotic arm Under the NASA's LoMMAs task, JPL developed a series of devices that are
- EAP are inducing a low actuation force limiting the applications that can use their current capability
- SPIE (March) covering actuators and applications and MRS (Dec.) -In recognition of this limitation two annual conferences were established: materials science
- between robot that is equipped with EAP actuators and human. A challenge was posed to the EAP community to have an arm wrestling